## Zero Smog® TL

# The next level in removing dangerous gases and particles



- > Extraction unit for up to 2 workplaces
- > Low noise levels
- > Portable, for placement under or next to the bench
- > Easy filter replacement
- > Audio-visual filter change alarm
- > Quick and simple installation with Easy-Click system
- > Variable speed setting
- > Active carbon foam filter for effective gas cleaning
- > Maintenance-free, brushless EC blower
- > Easily-operated



#### **Technical Data**


Dimensions (L x W x H)	335 x 330 x 445 mm
Weight	9 kg
Voltage	120 V, 60 Hz
Noise level	< 50 db (A)
Electrical power	120 W
Max. blower vacuum	3,000 Pa
Max. blower capacity	190 m³/h
Pre-filter	F7 fine dust filter
Compact filter	Particle filter H13 +10% carbon foam gas filter
Particle filter MPPS	<b>√99 95%</b>

## with ALFA Funnel Nozzle

- > Zero Smog® TL fume extraction unit
- > Stop valve with bench mounting bracket
- > Flexible, adjustable extraction arm, 1 m, ø 60 mm
- > Extraction hose, flexible, 3 m, ø 60 mm
- > ALFA funnel nozzle
- > Remote switch FT91000033N

Order No. 120 V ZEROSMOGTLKIT1N

## Zero Smog® TL





## Zero Smog® TL

- > Zero Smog® TL fume extraction unit
- > H13 particle filter and gas filter (10% active carbon foam filter)
- > F7 pre-filter

Order No.

ZEROSMOGTLN

## **Kit 1 ALFA Funnel Nozzle**

> Easy-Click-60 extraction arm with funnel, width 230 mm, height 100 mm, flexible arm, Ø 60 mm, lenght 1 m, with stop valve

Order No.

T005365199N

## **Filter Set H13**

> H13 particle filter and gas filter (10% active carbon foam filter) and ten F7 pre-filters

Order No.

T0058762858N



- > The optional WT Hub connects the Zero Smog TL to one or two WT or WX soldering stations and enables cost-efficient, synchronized functionality — the Zero Smog TL only works when the user is actively soldering.
- > Cable T0058764710 (required for WX connection only)

Order No.

T0058768767N

## Fine dust F7 pre-filters

> 10 F7 pre-filters

Order No.

T0058762857N



Order No.

FT91000033N