

# Fluke i30s AC/DC Current Clamp

# **Technical Data**



The i30s current clamp is based on Hall effect technology for use in measurement of both dc and ac current. The i30s may be used in conjunction with oscilloscopes and other suitable recording instruments for accurate non-intrusive current measurement.

# **Electrical specifications**

Specified current range: 30 mA to 30 A DC, 30 mA to 20 A AC rms Usable current range: 5 mA to 30 A DC, 30 mA to 20 A AC rms Crest factor: 1.4 Output sensitivity: 100 mV/A Accuracy (at +25 °C):  $\pm 1$  % of reading  $\pm 2$  mA **Resolution:**  $\pm$  1 mA Load impedance:  $> 100 \text{ k}\Omega$ **Conductor position sensitivity:**  $\pm$  1 % relative to centre reading Frequency range: DC to 100 kHz (- 0.5 dB) Phase shift below 1 kHz: < 2 degrees Temperature coefficient: ± 0.01 % of reading/°C Power supply: 9 V Alkaline, MN1604/PP3, 30 hours, low battery indicator Working voltage (see Safety Standards section): 300 V ac rms or dc

# **General specifications**

Maximum conductor size: 19 mm (.748 in) diameter Output connection: Safety BNC connector, supplied with safety 4 mm (.157 in) adapter Output zero: Manual adjust via thumbwheel Cable length: 2 m (6.56 ft) Operating temperature range: 0 °C to +50 °C (-32 °F to 122 °F) Storage temperature range (with battery removed): -20 °C to +85 °C (-4 °F to 185 °F) Operating humidity: 15 % to 85 % (non-condensing) Weight: 250 g (.55 lb)

# www.valuetronics.com



## **Safety standards**

BS EN 61010-1: 2001 BS EN 61010-2-032: 2002 BS EN 61010-031: 2002

# 300 Vrms, Category III, Pollution Degree 2

Use of the probe on uninsulated conductors is limited to 300 V acrms or dc and frequencies below 1 kHz.

#### **EMC Standards**

EN 61326: 1998 +A1, A2, & A3

**Ordering information** 

i30s AC/DC Current Clamp

#### 71 25 3.5 54 ø19 ÷ 15 BATTERY COVER 183 $\odot$ ON/OFF SWITCH ZERO ADJUST PR30 LED HEME LEM BNC CONNECTOR 30 5. FLEXIBLE STRAIN RELIEF

**Dimensions (HxWxD)** 

183 mm x 71 mm x 25 mm (7.2 in x 2.8 in x 1 in)



i30s connected to a Fluke 199C ScopeMeter.

# www.valuetronics.com

### Fluke. Keeping your world up and running.

#### **Fluke Corporation**

PO Box 9090, Everett, WA USA 98206 Fluke Europe B.V. PO Box 1186, 5602 BD Eindhoven, The Netherlands For more information call: In the U.S.A. (800) 443-5853 or Fax (425) 446-5116 In Europe/M-East/Africa +31 (0) 40 2 675 200 or Fax +31 (0) 40 2 675 222 In Canada (800) 36-FLUKE or Fax (905) 890-6866 From other countries +1 (425) 446-5500 or Fax +1 (425) 446-5116 Web access: http://www.fluke.com

©2006 Fluke Corporation. All rights reserved. Specifications subject to change without notice. Printed in U.S.A. 12/2006 2747115 D-EN-N Rev B